



# BH-50 FLOOR POLISH

### Description:

Bh-50 is ready to use floor polish to restore the shine of marbles, granite, vinyl and sealed hard wood surfaces.

### Key Properties:

Easy to apply  
Easy to maintain  
Added protection in heavy usage area

### Use Instruction:

**Full Surface Polishing:** 1. Deep clean the surfaces with a polish stripper to remove any existing polish and dirt. 2. Once the surface is dry, apply bh-50 with a clean microfiber mop to the surfaces using the 8 motion, work on areas in 1-2 meters at a time. 3. Allow 30 minutes between application for the product to dry. 4. Repeat 2-3 coats. 5. Leave the last coat to dry for 1 hour, and buff off with a floor polish disc for a perfect shine.

**Maintenance:** To a dry cleaned area, spray bh-50 directly on the surfaces and buff off with a floor polish disc for a perfect shine.

### Product Technical Information:

Appearance: Milky Liquid  
Colour: Milky  
pH Value@25 °C: 6.5-8.5  
Density @25 °C: 1.0-1.02

### Health and Safety:

Wear safety glasses and suitable gloves when handling. In case of eyes contact, rinse immediately with plenty of water. In case of accident seek medical advice immediately. Refer to MSDS.

### Storage:

Product must be stored closed in original packing, away from heat and direct sunlight. Keep away from the reach of children.

### Available Packing:

5 Liters