

### Description:

Bh-91 is a concentrated and low foaming liquid detergent that provides excellent cleaning for high efficiency washers. Its advanced formula that removes soils and stains leaving clothes clean and fresh.

### Key Properties:

Suitable for wide range of temperature  
Effective against greasy and oily soil

### Use Instruction:

This product is designed to be dosed automatically through a liquid dispensing system that is connected to auto washing machine at the rate of 2-3 ml per kg of load in Light Soil and 3-5ml per kg of load in Heavy Soil.

This product should be used in combination with an alkaline booster when washing heavy soiled loads at high temperature. Use low or normal temperature for delicate fabrics like wool, silk and other synthetic items.

### Product Technical Information:

Appearance: Liquid  
Colour: Blue  
pH Value@25 °C: 12.5-13.5  
Density @25 °C: 1.01-1.05

### Health and Safety:

Wear safety glasses and suitable gloves when handling. In case of eyes and skin contact, rinse immediately with plenty of water. In case of accident seek medical advice immediately. Refer to MSDS.

### Storage:

Product must be stored closed in original packing, away from heat and direct sunlight. Keep away from the reach of children.

### Available Packing:

25 Liters

Xi- Irritant



C- Corrosive

